## Smart Classroom Podium Use

1. Turn on the Lenovo computer by pushing the power button located on the right side panel near the bottom.



- 2. Press "On" on the Classroom Control Panel
- 3. If the "PC" button is not selected, press the "PC" button on the Classroom Control Panel
- 4. Adjust volume if needed on the Classroom Control Panel using the volume buttons, the lights above the buttons indicate level.
- 5. Note: The PC has touch screen capabilities.
- 6. To play a DVD/CD, Insert the DVD/CD into the DVD tray on right side panel.





7. Use "VLC" software to play the DVD/CD

## **Smart Classroom Podium Use**